

What's in the box?

- 2x Door Guide Brackets
- 2x Door Guide Slides
- 4x Countersunk Screws





- Position the bracket with slider in place on the side wall of the van, with the bend at the rear sitting against the structural rear pillar.
- Ensure the bracket is level and the white part of the door arm only slides against the door guide slide before screwing in place.